

Trailer loading guidelines

For recovered roof insulation boards

BEFORE YOU LOAD

- 1 Leave room for forklift blades**
Allow clearance underneath the bottom board.
- 2 Load material 90 inches high**
90 inches = 7 feet 6 inches.
- 3 Do not load broken or wet boards**
- 4 No tapered material**
- 5 Material must be free of mold**

APPROVED LOADING

Use these examples when arranging insulation boards.



INAPPROPRIATE LOADING

Do not load material as shown below.



Questions before loading?

Contact Disposal Alternatives: 617-975-2000

disposalalternatives.net